



Compatibility of *Vision Air* versions with Windows™ operating systems

	Windows XP (SP1, SP2, SP3)	Windows Vista	Windows 7	Windows 8	Windows 10	Windows 11
Vision Air 1.1	–	–	✓	✓	–	–
Vision Air 2.0-2.0.5	–	–	✓	–	✓	–
Vision Air 2.0.7 or higher	–	–	✓	–	✓	✓

Only 64-bit operating systems are supported

	Windows Server 2008 R2 (32 & 64 bit)	Windows Server 2012 64 bit	Windows Server 2012 R2 64 bit	Windows Server 2016	Windows Server 2019
Vision Air Server 1.1	✓	–	–	–	–
Vision Air Server 2.0-2.0.5	–	✓	✓	–	–
Vision Air Server 2.0.7 or higher	–	–	✓	✓	✓

Operating System Language must be English (during installation only)