

Booster10A

Booster10A

1	Booster10A Dummy cell	AUTSERV.BSTR10.CELL
----------	------------------------------	----------------------------

100 mOhm dummy cell for testing the Booster10A.



1	BST.DIO.CABLE	Booster digital interface cable
----------	----------------------	--

Digital control cable for the Autolab Booster10A and Booster20A.



1	CABLE.PWR	Power cable
----------	------------------	--------------------

Standard power cable for Autolab instruments and accessories.

