



Application Note AN-PAN-1031

Effectively monitoring hydrogen peroxide online in salmon farms

Salmon farms have become more popular in the past several years. Our ever-growing population has increased the demand for salmon which influences their cultivation. In these aquatic farms, the fish live in limited space in open net cages. Parasites such as salmon lice can multiply quickly due to the high density of fish. One possibility to combat lice infestation is to use baths with dilute concentrations of hydrogen peroxide (H_2O_2) as a delousing agent. The salmon are treated in these baths for up to 20 minutes until the lice detach and die.

While it is true that hydrogen peroxide decomposes relatively quickly, it can be deadly

for salmon in high amounts. The concentration must therefore always lie within strict specifications during treatment.

This Process Application Note details the online analysis of H_2O_2 in the salmon treatment bath. The [2060 TI Process Analyzer](#) from Metrohm Process Analytics requires less than two minutes per titration analysis. This online process analyzer helps keep the salmon healthy and safe during treatment by permitting more concentration determinations in less time than manual analysis and always guaranteeing the correct H_2O_2 dosage.

INTRODUCTION

The industrial farming of plants and animals for human consumption is nothing new, although generally this is done on land (agriculture). Aquaculture is the equivalent to agriculture in terms of growing animals and plants for food, but farmed from water sources. Salmon farming has grown in popularity over the years, from the coasts of Norway and Scotland to as far away as New Zealand, Chile, and Alaska [1]. The process of growing salmon is contained either in a net or pond and is controlled from egg to market

(Figure 1). An unfortunate side effect of holding such a large volume of fish in a contained area is the proliferation of salmon lice (*Lepeophtheirus salmonis*), which must be killed off (delousing) for a healthy population of fish to survive. The parasites attach to and feed off of the salmon, causing anemia and even death. The lice can spread quickly during the grading and harvesting processes because of the large disturbances caused.



Figure 1. Illustration of the Atlantic salmon production process at an aquatic farm (repurposed from [1]).

One of the salmon delousing treatments available is hydrogen peroxide (H_2O_2). A diluted bath of H_2O_2 is prepared in which the fish are introduced for up to 20 minutes, and this removes the attached parasites, which can then be filtered from the water. The benefits of using H_2O_2 are numerous – it is easy to purchase, it is a non-medicinal treatment, and it rapidly degrades into water and oxygen as byproducts. Challenges remain regarding the efficiency of dosing, mixing, and the distribution of H_2O_2 in the salmon treatment tank to prevent

overdosing, which can cause oxidative stress in the fish, the bleaching of skin/scales, and even death. Therefore, quick analysis and response times are critical. The Metrohm Process Analytics 2060 TI Process Analyzer (Figure 2) can monitor the concentration of H_2O_2 and be used to control the dose rate accurately into the salmon treatment tank, ensuring that the delousing treatment process runs within specifications. These online process analyzers are currently in use at several salmon farms.



Figure 2. 2060 TI Process Analyzer used for online monitoring of hydrogen peroxide in salmon delousing baths.

APPLICATION

The H_2O_2 concentration is measured titrimetrically with cerium (IV) using a Pt-ring electrode and reference electrode (Ag/AgCl/KCl) to determine the endpoint with dynamic endpoint titration (DET). The analysis

frequency is fully optimized, and the typical analysis time is less than two minutes, ensuring timely control of the H_2O_2 concentration in the bath.

Table 1. Hydrogen peroxide concentration range used in the delousing process at salmon farms.

Parameters	Concentration [g/L]
H_2O_2	0–2500

REMARKS

Other process applications are available for this industry including the determination of alkalinity, calcium, water hardness, free fatty

acids (in fish oil), iron, phosphate, and many more.

CONCLUSION

A wide range of hydrogen peroxide concentrations in salmon farm delousing baths can be measured online quickly and reliably using the Metrohm Process Analytics 2060 TI Process Analyzer. Furthermore, this analyzer can

provide automated analysis results for the salmon treatment tank, avoiding overdosing, which can cause oxidative stress in the fish, skin/scale bleaching, and death.

RELATED APPLICATION NOTES FOR THE FOOD & BEVERAGE INDUSTRY

[AN-PAN-1029 Peracetic acid \(PES\) as disinfectant for PET bottles](#)

[AN-PAN-1054 Online monitoring of hydrogen peroxide during the CMP process](#)

[AN-PAN-1055 Monitoring quality parameters in](#)

[standard cleaning baths](#)

[AN-T-025 Hydrogen peroxide content in aqueous solutions](#)

[AN-NIR-095 Quality Control of Hand Sanitizers](#)

RELATED DOCUMENTS

[Brochure: Fishery & Aquaculture – reliable online, inline, and atline analysis systems for](#)

[optimizing aquaculture plants](#)

[Brochure: 2026 Hydrogen Peroxide Analyzer](#)

BENEFITS FOR ONLINE ANALYSIS OF DELOUSING

- Detect treatment upsets quickly (e.g., incorrect chemical dosing) via automated analysis
- Improved manufacturing efficiency (avoid lower fish yields and harvesting disturbances)
- Monitor multiple treatment baths (up to 10) for more savings per measurement point and results



REFERENCES

1. *Salmon Farming Industry Handbook 2021*; Mowi Industry, 2021.

CONTACT

メトロームジャパン株式会社
143-0006 東京都大田区平
和島6-1-1
null 東京流通センター アネ
ックス9階

metrohm.jp@metrohm.jp

CONFIGURATION



2060 Process Analyzer

2060 Process Analyzerは、無数のアプリケーションに対応するオンライン湿式化学アナライザーです。このプロセスアナライザーは、「ヘーシックキャビネット」と呼ばれる中核フラットホームによって構成される新たなモジュラー式コンセプトを提供するものです。

ヘーシックキャビネットは、2つの部分から構成されます。上部はタッチスクリーンと産業用PCを含みます。下部には、実際の分析のためのハードウェアが格納されるフレキシブルな湿式部が含まれます。基本湿式部の容量が分析課題を解決するのに充分でない場合、最も困難なアプリケーションでも解決できる十分なスペースを確保するため、ヘーシックキャビネットを4つまでの追加湿式部キャビネットに拡張することが可能です。追加キャビネットは、各湿式部キャビネットを、アナライザーの稼働時間を増加させる内蔵式(非接触式)レベル検出を有する試薬キャビネットと組み合わせるという方法によってコンフィグレーションすることかできます。

2060 Process Analyzerは様々な湿式化学技術を提供します: カール フィッシャー滴定、光度測定、直接測定、および標準追加メソッドです。

プロジェクトのすべての要求を満たすべく(もしくはお客様のすべての必要性を満たすため)、頑丈な分析ソリューションを保証するためのサンプルフレコンティショニングシステムをご利用いただくことも可能です。弊社は、冷却や加熱、減圧、脱気、ろ過などのような、いかなるサンプルフレコンティショニングシステムでも提供することかできます。